




Samsung SGH A707 Keypad Replacement

Replace a keypad on your Samsung SGH A707 phone.

Written By: yfm



INTRODUCTION

Use this guide to replace your Samsung SGH A707 phone's keypad.

TOOLS:

- [Tweezers](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Battery



- Press on the markings on the cover and pull it down to reveal the battery.

Step 2



- Use your fingers to pull the battery out of its position. You may also flip the phone and the battery will fall out.

Step 3



- Here is the phone without the battery.

Step 4 — Logic Board



- Unscrew the six screws on the back of the phone using the Phillips #0 screw driver.

Step 5



- Use the prying tool the pry off the phone's plastic frame.

Step 6



- Use the prying tool to disconnect the rectangular connector.

Step 7




- Use the prying tool to disconnect the small connector.

Step 8




- Gently pull off the circuit board.

Step 9



- Here is the phone without the logic board.

Step 10 — Keypad



- Hold the phone and gently separate the circuit board that holds the dome switches and the front face of the phone, revealing the rubber keyboard.

Step 11




- Here is the phone without the dome switch circuit board.

Step 12



- Here is the phone and the rubber keyboard.

Step 13



- Here is the rubber keyboard and the dome switch circuit board. A quick inspection of these elements can reveal keypad malfunctions. Look for dirt or debris that do not belong there.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-29 03:40:25 AM.